
Remote Touch (if equipped)

The Remote Touch can be used to operate the navigation screens and configure settings.

■ Basic operation



1 "MENU" button
Press to display the "Menu" screen.


2 "∧•∨" button
Press to change the scale of the map and to scroll the list screen.

3 "MAP/VOICE" button
Press to repeat a voice guidance, cancel the screen scroll, start guidance, and display the current position.

4 Remote Touch knob
Move in the desired direction to select a function, letter and map screen button.

5 "ENTER" button
Press to enter the selected function, letter or map screen button.


■ Menu




Press the "MENU" button on the Remote Touch to display the "Menu" screen.

1 "Destination"
2 "Info/Apps" ("Info")
3 "Setup"
4 "Radio" (→P.61)
5 "Media" (→P.60)
6 "Climate" (→P.64)
7 "Phone" (→P.53)
8 "Display" (→P.43)

■ Display





Press the "MENU" button on the Remote Touch and select "Display" on the "Menu" screen.

1 Displays the screen in "Day Mode" with the headlight switch on*
2 Turns the screen off
3 Change function
4 Adjust contrast/brightness

*: The displays condition is not changed to night mode even if headlight switch is turned on when the vehicle is in a bright area such as outside in direct sunlight or the instrument panel light control dial is turned fully to upper.

■ Screen scroll operation



To scroll over the map, place the pointer in a position near the desired destination and then press and hold the "ENTER" button on the Remote Touch.


1 Indicates the street name, city name, etc. for the selected point
2 Displays various information for the selected point (if available)
3 Indicates the distance from the current position to the pointer
4 Displays the "Map Mode" screen
5 Zooms in on the map
6 Zooms out on the map

■ Setting a route

While route guidance is operating, you can change the route using the following method.



Select "Route".
The following settings can be accessed



1 Detour setting
2 Route preferences
3 Route overview
4 Pause and resume route guidance

Some functions are unavailable while the vehicle is in motion. Refer to the "Navigation System Owner's Manual".

Navigation System (if equipped)

Register home




1 Press the “MENU” button on the Remote Touch.
Please refer to P.42 for the Remote Touch operation.




2 Select “Setup”.



3 Select “Navigation”.



4 Select “Home”.
5 Select “Set Home”.
6 Select “Address”.



7 Select “City”.

8 Input a city name and select “OK”.

9 Select the screen button of the desired city name from the displayed list.

For security reasons, use a point close to your home instead of your actual home address.

10 Input the street name and select “OK”.

11 When the desired street name is found, select the corresponding button.

12 Input a house number and select “OK”.

13 Select “Enter”.

14 Select “OK”.

■ Destination input——Search by address

Select by city name




1 Press the “MENU” button on the Remote Touch.
Please refer to P.42 for the Remote Touch operation.



2 Select “Destination”.



3 Select “Address”.



4 Select “City”.



5 Input a city name and select “OK”.
6 Select the screen button of the desired city name from the displayed list.
7 Input the street name and select “OK”.
8 When the desired street name is found, select the corresponding screen button.
9 Input a house number and select “OK”.
10 Select “Go to”.
11 Select “OK”.


Select by street address




1 Press the “MENU” button on the Remote Touch.
Please refer to P.42 for the Remote Touch operation.




2 Select “Destination”.



3 Select “Address”.



4 Select “Street Address”.



5 Input a house number and select "OK".

6 Input the street name and select "OK".

7 When the desired street name is found, select the corresponding screen button.

8 Input a city name and select "OK".

9 Select the screen button of the desired city name from the displayed list.

10 Select "Go to".

11 Select "OK".

■ Destination input——Search points of interest by name




1 Press the "MENU" button on the Remote Touch.
Please refer to P.42 for the Remote Touch operation.



2 Select "Destination".



3 Select "Point of Interest".



4 Select “Name”.



5 Input the name of the point of interest and select “OK”.

6 Select the screen button of the desired destination.

7 Select “Go to”.

8 Select “OK”.

■ Destination input—— Search points of interest by category




1 Press the “MENU” button on the Remote Touch.
Please refer to P.42 for the Remote Touch operation.



2 Select “Destination”.



3 Select “Point of Interest”.



4 Select “Category”.



5 Select “Near a Destination”.

6 Select the screen button of the desired destination and set the search point.

7 Select the desired point of interest category from the displayed list.

8 Select the screen button of the desired item.

9 Select “Go to”.

10 Select “OK”.

■ Destination input —— Search points of interest by phone number




1 Press the “MENU” button on the Remote Touch.
Please refer to P.42 for the Remote Touch operation.

STEP 2



2 Select “Destination”.

STEP 3



3 Select “Point of Interest”.

STEP 4



4 Select “Phone #”.

STEP 5



5 Input a phone number and select “OK”.
6 Select “Go to”.
7 Select “OK”.

Hands-free System For Cellular Phone (vehicles with a navigation system)

Bluetooth® phone pairing

Compatible Bluetooth®-equipped phones can be connected to the vehicle, enabling hands-free operation. Please refer to the cellular phone manufacturer's user guide for pairing procedures, or go to "www.lexus.com/MobileLink" for more phone information.



To use a Bluetooth® phone, it is necessary to first register it in the system.

1 Press the "MENU" button on the Remote Touch.
Please refer to P.42 for the Remote Touch operation.



2 Select "Phone".



3 Select "Yes".



4 Enter the passcode displayed on the screen into the phone.
Refer to the cellular phone user's manual for cellular phone operation.

5 If a completion message is displayed, registration is complete.

Phonebook transfer



1 Press the "MENU" button on the Remote Touch.
Please refer to P.42 for the Remote Touch operation.



2 Select "Setup".



3 Select "Phone".

4 Select "Phonebook".

5 Select "Manage Contacts".



6 Select “Transfer Contacts”.

7 Select “Update Contacts”.



8 Transfer the phonebook data to the system by using the cellular phone.
Refer to the cellular phone user’s manual for cellular phone operation.

Phonebook transfer may not be possible depending on phone model.

■ Registering a speed dial




1 Press the “MENU” button on the Remote Touch.
Please refer to P.42 for the Remote Touch operation.




2 Select “Setup”.



3 Select “Phone”.
4 Select “Phonebook”.
5 Select “Manage Speed Dials”.




6 Select “New”.




7 Select the data you want to register.
8 Select the desired phone number.
9 Select the screen button you want to register in.
10 The registration completion message is displayed on the screen.

■ Calling by name

You can call by giving a voice command. For operation and command of the voice recognition, refer to the “Navigation System Owner’s Manual”.



1 Press .




2 Following the system guidance, wait for the beep and then say “Call” and the desired name.

3 Following the system guidance, wait for the beep and say “Dial”.

: Pressing this switch turns the voice command system on. Say a command after the beep.

■ Calling by speed dial




1 Press .

STEP 2



2 Select "Speed Dials".

STEP 3



3 Select the desired number to call.

■ Calling using SMS/MMS message

STEP 1



1 Press the "MENU" button on the Remote Touch.
Please refer to P.42 for the Remote Touch operation.

STEP 2



2 Select "Phone".



3 Select “Messages”.

4 Select “SMS/MMS” tab.


5 Select the desired received message from the displayed list.

6 Press on the steering wheel.

■ Receiving a call



1 When a call is received, this screen is displayed with a sound.



2 Press on the steering wheel to talk on the phone.

To refuse the call, press on the steering wheel.

Audio System (vehicles with a navigation system)

■ Audio control screen

Follow the procedure below to display the audio control screen.

STEP 1



1 Press the "MENU" button on the Remote Touch.
Please refer to P.42 for the Remote Touch operation.


STEP 2



2 Using the Remote Touch, select "Radio" or "Media" and press the "ENTER" button.

■ Remote control (steering wheel switches)

Some audio features can be controlled using the switches on the steering wheel.



1 Turns the power on, selects an audio source

2 Increases/decreases volume

3 Radio mode: Selects a preset station
Audio CD mode: Selects a track
MP3/WMA disc mode: Selects a file
DVD mode: Selects a chapter
iPod mode: Selects a track

Basic operation



1 Function menu tab

2 Sound quality modes

3 "MEDIA" button

DISC: DVD player/CD player

BT audio: Bluetooth® audio

AUX: Auxiliary audio device

USB: USB memory

iPod: iPod

4 Power/Volume

5 "RADIO" button

AM: AM radio

FM: FM radio

SAT: Satellite radio

Apps: Internet radio broad cast

Radio



1 Station selector

2 Scanning for receivable stations

3 Using HD Radio™ Technology

4 Adjusting the frequency

5 Preset tuning/seeking the frequency

6 "RADIO" button

Entering station presets

1 Select the desired station by using the tune, the seek or the scan function.

2 Using the Remote Touch, select one of the screen buttons (1-6), then press and hold the "ENTER" button until a beep is heard, indicating that the station has been set.

DVD player/CD player

Playing an audio CD



1 Selecting a track
2 Random playback
3 Repeat play
4 Playback/pause
5 CD eject

Playing a CD with MP3/WMA files



1 Folder selection
2 File selection
3 Random playback
4 Repeat play
5 Playback/pause
6 CD eject

Playing a DVD



1 Rewind
2 Stop
3 Playback/pause
4 Image display (full screen)
5 Fast forward
6 Chapter selection
7 DVD eject

Operating an iPod



1 Track selection
2 Shuffle playback
3 Repeat play
4 Playback/pause
5 Selecting a play mode

Air Conditioning System (vehicles with a navigation system)



1 Driver side temperature display
2 Driver side temperature control
3 Fan speed control
4 Air flows to the feet and the windshield defogger operates
5 Outside temperature
6 Air outlet selector
7 Passenger side temperature control
8 Passenger side temperature display
9 Micro dust pollen filter
10 Dual mode
11 Cooling and dehumidification function on/off
12 Outside air/recirculated air mode button
13 "OFF" button
14 Automatic mode
15 Rear window and outside rear view mirror defoggers switch
16 Windshield defogger
17 Windshield wiper de-icer

■ Using the automatic mode

Press 14 to turn on the airflow and 2 to adjust the temperature.

■ Adjusting the temperature

In dual mode, driver and passenger side temperature settings can be adjusted separately.


Press 7 to adjust the temperature for the passenger side.
To cancel the dual mode, press 10.

Hands-free System For Cellular Phone (vehicles without a navigation system)

■ Bluetooth® phone pairing

Compatible Bluetooth®-equipped phones can be connected to the vehicle, enabling hands-free operation. Please refer to the cellular phone manufacturer's user guide for pairing procedures, or go to"www.lexus.com/MobileLink" for more phone information.

STEP 1




To use a Bluetooth® phone, it is necessary to first register it in the system.

1. Press [phone switch] or [talk switch].
2. Press [talk switch] and say "Pair phone".
3. Press [talk switch] and say a name*.

   *: This name will be used to identify your phone in the case that more than one phone has been registered to the system.
4. Press [talk switch] and say "Confirm" to display the passkey.
5. Enter the passkey shown on the display into the phone.
   Refer to the cellular phone user's manual for cellular phone operation.
6. Once the voice guidance for registration completion is finished, press [off-hook switch].

> [talk switch]: Pressing this switch turns the voice command system on. Say a command after the beep.

■ Calling by number



1 Press and say "Dial by number".

2 Press and say the phone number.


3 Dialing

a. Press .

b. Press and say "Dial".

■ Calling by name

You can call by saying a voice tag registered in the phonebook. For setting the voice recognition, refer to the "Owner's Manual".



1 Press and say "Dial by name".

2 Press and say a contact name.

3 Dialing


a. Press .

b. Press and say "Dial".

: Pressing this switch turns the voice command system on. Say a command after the beep.

■Calling by speed dial

STEP 1



1 Press .


STEP 2



2 Press the desired preset button.

3 Press .

■ Phonebook transfer




1. Press .
2. Press and say "Phone book".
3. Press and say "Add entry".
4. Press and say "By phone".
5. Press and say "Confirm".
6. Transfer the phonebook data to the system using the cellular phone.
   Refer to the cellular phone user's manual for cellular phone operation.
7. Press and say "Previous" or "Next" until the desired data is displayed.
8. Press and say "Confirm".
9. Press and say the desired name.
10. Press and say "Confirm".
11. Press and say "Confirm" again.

Phonebook transfer may not be possible depending on phone model.

: Pressing this switch turns the voice command system on. Say a command after the beep.

■Changing the registered name



1 Press [phone switch icon].

2 Press [talk switch icon] and say "Phone book".

3 Press [talk switch icon] and say "Change name".

4 Press [talk switch icon] and say the desired name.


5 Press [talk switch icon] and say "Confirm".

6 Press [talk switch icon] and say the new name.

7 Press [talk switch icon] and say "Confirm"

[talk switch icon]: Pressing this switch turns the voice command system on. Say a command after the beep.

■ Registering a speed dial





1. Press .
2. Press and say "Phone book".
3. Press and say "Set speed dial".
4. Select the data to be registered.
5. Press and say the desired name.
6. Press and say "Confirm".
7. Press the desired preset button.
8. Press and say "Confirm"

: Pressing this switch turns the voice command system on. Say a command after the beep.

Audio System (vehicles without a navigation system)

■ Basic operation

Type A



1 Power/Volume

2 Audio sources

AM•SAT: AM radio/Satellite radio
FM1/FM2: FM radio
CD•AUX: CD player/Auxiliary audio device/USB memory/iPod/Bluetooth® audio

3 Sound quality modes

Type B



1 Power/Volume

2 Audio sources

AM•FM: AM radio/FM radio
SAT: Satellite radio
CD•AUX: CD player/Auxiliary audio device/USB memory/iPod/Bluetooth® audio

3 Sound quality modes

Type C



1 Power/Volume

2 Audio sources

AM: AM radio
FM: FM radio
CD: CD player
AUX•USB: Auxiliary audio device/USB memory/iPod/Bluetooth® audio

3 Sound quality modes

Radio

Type A



1 Displaying text message
2 Station selector
3 Scanning for receivable stations
4 Adjusting the frequency
5 Changing the program type
6 Seeking the frequency

Type B



1 Station selector
2 Displaying text message
3 Traffic information button
4 Adjusting the frequency
5 Scanning for receivable stations
6 Changing the program type
7 Seeking the frequency

Type C



1 Station selector
2 Scanning for receivable stations
3 Displaying text message
4 Adjusting the frequency
5 Station selector
6 Seeking the frequency


Entering station presets

1. Select the desired station by using the tune, the seek or the scan function.
2. Press and hold one of the preset buttons (1-6) until you hear a beep, indicating that the station is set.

CD player


Playing an audio CD

Type A



1 Displaying text message
2 CD eject
3 Repeat play
4 Search play
5 Playback
6 Selecting a track
7 Random playback

Type B



1 CD insert
2 CD eject
3 Repeat play
4 Playback/pause
5 Displaying text message
6 Search play
7 CD selection
8 Playback
9 Selecting a track
10 Random playback


Type C



1 CD insert
2 CD eject
3 Repeat play
4 Playback/pause
5 Search play
6 Displaying text message
7 CD selection
8 Playback
9 Selecting a track
10 Random playback

Playing a CD with MP3/WMA files

Type A



1 Displaying text message
2 CD eject
3 Repeat play
4 Search play
5 File selection
6 Playback
7 Folder selection
8 Selecting a file
9 Random playback

Type B



1 CD insert
2 CD eject
3 Repeat play
4 Playback/pause
5 Displaying text message
6 Folder selection
7 File selection
8 Search play
9 CD selection
10 Playback
11 Selecting a file
12 Random playback

Type C



1 CD insert
2 CD eject
3 Repeat play
4 Playback/pause
5 Search play
6 Displaying text message
7 Folder selection
8 File selection
9 CD selection
10 Playback
11 Selecting a file
12 Random playback

Loading a CD

Type A

Insert a CD.

Type B and C

1 Press the "LOAD" button.

"WAIT" is shown on the display.

2 When the indicator on the slot turns from amber to green, insert a CD.

The display changes from "WAIT" to "LOAD".

Loading multiple CDs (Type B and C)

1 Press and hold the "LOAD" button until you hear a beep.

"WAIT" is shown on the display.

2 When the indicator on the slot turns from amber to green, insert a CD.

The display changes from "WAIT" to "LOAD".

The indicator on the slot turns to amber when the CD is being inserted.


3 When the indicator on the slot turns from amber to green, insert the next CD.

Repeat the procedure for the remaining CDs.

To cancel the operation, press the "LOAD" button. If you do not insert a disc within 15 seconds, loading will be canceled automatically.


Operating an iPod

Type A




1 Displaying text message
2 Repeat play
3 Playback/pause
4 Go back
5 iPod menu/Song selection
6 Playback
7 Song selection
8 Shuffle playback

Type B



1 Repeat play
2 Playback/pause
3 Go back
4 Displaying text message
5 iPod menu/Song selection
6 Playback
7 Song selection
8 Shuffle playback


Type C



1 Repeat play
2 Playback/pause
3 Go back
4 Displaying text message
5 iPod menu/Song selection
6 Playback
7 Song selection
8 Shuffle playback


■ Remote control (steering wheel switches)

Some audio features can be controlled using the switches on the steering wheel.



1 Turns the power on, selects an audio source
2 Increases/decreases volume
3 Radio mode: Selects a radio station
CD mode: Selects a track, file (MP3 and WMA) and disc
iPod mode: Selects a song

Air Conditioning System (vehicles without a navigation system)



1 Driver's side temperature control buttons
2 Windshield defogger button
3 Driver's side temperature display
4 Fan speed display
5 Air outlet display
6 Passenger's side temperature display
7 Micro dust and pollen filter mode button
8 Passenger's side temperature control buttons
9 Dual mode button
10 Cooling and dehumidification function on/off button
11 Outside/recirculated air mode button
12 Air outlet selector button
13 Fan speed control buttons
14 "OFF" button
15 Automatic mode button
16 Rear window and outside rear view mirror defoggers switch

Using the automatic mode

Press 15 to turn on the airflow and 1 to adjust the temperature.

Adjusting the temperature

To simultaneously adjust the driver's side and passenger's side temperature settings

Press 9 to turn the "DUAL" indicator off and then press 1.

To individually adjust the driver's side and passenger's side temperature settings

Press 9 or 8 to turn the "DUAL" indicator on and then press 1 or 8.

Voice Command System (vehicles with a navigation system)

■ Basic operation

NOTE: When inputting voice commands you must wait until after the beep to speak.



1. Press on the steering wheel.
2. - If you know the command:
   Press again.
   - If you do not know the command:
   Follow the voice guidance to learn the command and then press again.
3. Say a command after the beep.

■ Important voice commands information and tips

- Voice commands can be used while driving.
- You must wait until after the beep to say a command.
- In vehicles with a navigation system, a large TALK icon will appear on the navigation screen to prompt you to say a command.
- If you know what command to use, you can press at any time to interrupt the voice guidance.

■ Command list

Set a Destination

Command	Action
“Find Nearby <POI category>”	Displays a list of <POI category*> near the current position.
“Enter an Address”	Enables setting a destination by saying the address.
“Go Home”	Displays the route to home.
“Call Destination Assist”	Connects Lexus Enform with Safety Connect response center.
“Destination by Phone Number”	Enables setting a destination by saying the phone number.

*: For example; Gas stations, Restaurants, etc.

Use the Phone

Command	Action
“Call <name> <type>”	Calls made by saying a name from the phonebook. For example: Say “Call John Smith”, “Call John Smith, mobile” etc.
“Dial <number>”	Calls made by saying the phone number. For example: Say “Dial 911”, “Dial 5556667777” etc.
“International Call”	Calls international numbers by saying the phone number.

Play Music

Command	Action
“Play Artist <name>”	Plays tracks by the selected artist. For example: Say “Play artist <XXXXX>”*
“Play Album <name>”	Plays tracks from the selected album. For example: Say “Play album <XXXXX>”*
“Play Song <name>”	Plays the selected track. For example: Say “Play song Summertime”, “Play song Concerto in A Major” etc.
“Play Playlist <name>”	Plays tracks from the selected playlist. For example: Say “Play playlist My Favorite Songs”, “Play Playlist Classic Hits” etc.

*: Say the desired artist name or album name in the place of the “<>”.

Get Information

Command	Action
"Traffic"	Displays the traffic incident list.
"Weather"	Displays weather information.
"Sports Scores"	Displays the sports list.
"Stock Quotes"	Displays the stocks list.
"Fuel Prices"	Displays the fuel prices list.
"Lexus Insider"	Displays the Lexus insider list.

Select audio mode

Command	Action
"Radio", "AM", "FM", "Satellite radio", "Disc", "Auxiliary", "Bluetooth* audio", "iPod", "USB audio"	Change the audio mode.
"Audio on"	Turns the audio system on.
"Audio off"	Turns the audio system off.

*: Bluetooth is a registered trademark of Bluetooth SIG, Inc.

Climate/air conditioning system command

Command	Action
"Automatic climate control"	Turns air conditioning system on and off.
"Warmer"	Turns temperature up.
"Cooler"	Turns temperature down.


"Select audio mode" and "Climate/air conditioning system command" are enabled when expanded voice commands are turned "On". Refer to the "Navigation System Owner's Manual".

Portable Audio Device Ports

These ports can be used to connect a portable audio device and listen to it through the vehicle's speakers.



Press down and release the lid.



1 USB port
2 AUX port


Garage Door Opener (if equipped)

The garage door opener can be programmed to operate garage doors, gates, entry doors, door locks, home lighting systems, security systems, and other devices.

The garage door opener (HomeLink® Universal Transceiver) is manufactured under license from HomeLink®.

■ Programming the HomeLink®


The HomeLink® compatible transceiver in your vehicle has 3 buttons which can be programmed to operate 3 different devices. Refer to the programming method below appropriate for the device.



1 Indicator light

2 Buttons

■Programming HomeLink®



1 Hold your hand-held transmitter 1 to 3 in. (25 to 75 mm) of the HomeLink® buttons.

2 Press and hold down the desired HomeLink® button.

3 For U.S.A. owners:

While pressing the HomeLink® button, press and hold down the button on the hand-held transmitter until the indicator light changes from a slow to a rapid flash.

For Canadian owners:

While pressing the HomeLink® button, repeatedly press and release (cycle) the button on the hand-held transmitter every 2 seconds until the indicator light changes from a slow to a rapid flash.

If your garage door is of the rolling code type:

4 Press the training button on the motor-head unit in your garage.

5 Press and hold the vehicle's programmed HomeLink® button for 2 seconds and release it. Repeat this step once again.

If the door does not open, press and release the same button once again.

Programming other devices

For U.S.A. owners:


To program an entry gate, see the Owner's Manual.

To program other devices, contact your Lexus dealer.

For Canadian owners:

To program all other devices, follow the same procedure as for garage door programming.

Operating HomeLink®




Press the appropriate HomeLink® button. The indicator light should come on.

Safety Connect (if equipped)

Safety Connect is a subscription-based telematics service that uses Global Positioning System (GPS) data and embedded cellular technology to provide safety and security features to subscribers. Safety Connect is supported by Lexus' designated response center, which operates 24 hours per day, 7 days per week.

Safety Connect service is available by subscription on select, telematics hardware-equipped vehicles.

System components



1 Microphone

2 LED light indicators

3 "SOS" button

■ Services

Subscribers have the following Safety Connect services available:

- **Automatic Collision Notification***

  In case of either airbag deployment or severe rear-end collision, the system is designed to automatically call the response center. The responding agent receives the vehicle's location and attempts to speak with the vehicle occupants to assess the level of emergency. If the occupants are unable to communicate, the agent automatically treats the call as an emergency, contacts the nearest emergency services provider to describe the situation, and requests that assistance be sent to the location.

  *: U.S. Patent No. 7,508,298 B2

- **Stolen Vehicle Location**

  If your vehicle is stolen, Safety Connect can work with local authorities to assist them in locating and recovering the vehicle. After filing a police report, call the Safety Connect response center at 1-800-25-LEXUS (1-800-255-3987) and follow the prompts for Safety Connect to initiate this service.

  In addition to assisting law enforcement with recovery of a stolen vehicle, Safety-Connect-equipped vehicle location data may, under certain circumstances, be shared with third parties to locate your vehicle. Further information is available at Lexus.com.

- **Emergency Assistance Button (SOS)**

  In the event of an emergency on the road, push the "SOS" button to reach the Safety Connect response center. The answering agent will determine your vehicle's location, assess the emergency, and dispatch the necessary assistance required.

  If you accidentally press the "SOS" button, tell the response-center agent that you are not experiencing an emergency.

- **Enhanced Roadside Assistance**

  Enhanced Roadside Assistance adds GPS data to the already included warranty-based Lexus roadside service.

  Subscribers can press the "SOS" button to reach a Safety Connect response-center agent, who can help with a wide range of needs, such as: towing, flat tire, fuel delivery, etc. For a description of the Roadside Assistance services and their limitations, please see the Safety Connect Terms and Conditions, which are available at Lexus.com.

■ Subscription

After you have signed the Telematics Subscription Service Agreement and are enrolled, you can begin receiving services.

A variety of subscription terms is available for purchase. Contact your Lexus dealer, call 1-800-25-LEXUS (1-800-255-3987) or push the "SOS" button in your vehicle for further subscription details.

Lexus Enform with Safety Connect (if equipped)

Lexus Enform and Safety Connect are subscription-based telematics services that use Global Positioning System (GPS) data, embedded cellular technology and XM satellite data services to provide safety and security as well as convenience features to subscribers.
Lexus Enform and Safety Connect services are supported by Lexus' designated response center, which operates 24 hours per day, 7 days per week.
Lexus Enform service is available by subscription on select, telematics hardware-equipped vehicles.
For details, refer to the "Owner's Manual" and "Navigation System Owner's Manual".

■Services

With an active Lexus Enform subscription, the following features are available:

● Safety Connect features (→P.84)

- Automatic collision notification*1
- Stolen vehicle location
- Emergency assistance button (SOS)
- Enhanced roadside assistance

● Apps

Apps is a service that enables the usable contents of a mobile phone to be displayed on and operated from the navigation system screen. Before Apps can be used, a few settings need to be performed.

● Destination Assist

Destination Assist provides you with live assistance for finding destinations via the Lexus Enform response center. You can request either a specific business, address, or ask for help locating your desired destination by category, such as restaurants, gas stations, shopping centers or other points of interest (POI).
After you tell the agent your choice of destination, its coordinates are sent wirelessly to your vehicle's navigation system.

- **eDestination**
  With the eDestination feature, you can go online, via the Lexus.com owner's Web site, to select and organize destinations of your choice and then wirelessly send them to your vehicle's navigation system.
  You can store up to 200 locations online to access and update at any time.
  Your locations can be organized into up to 20 personalized folders.
  You must first go online at www.lexus.com/drivers/ to view the Owners site where you will need to register and log in. After this, personalized folders that contains the locations to be sent to your vehicle can be created. (See Lexus Enform with Safety Connect Guide for more information.)
- **XM Sports and Stocks***2
  XM Sports and Stocks is a service included with XM satellite radio subscriptions. These services are also available with an XM TravelLink subscription. With this service, you can receive updates via the navigation system on your personally selected sports teams and stocks.
- **XM Fuel Prices***3
  XM Fuel Prices is a service included with an XM TravelLink subscription. It enables the navigation system to display current fuel prices and gas station locations, which can be set as a destination if desired.
- **XM NavWeather™***3
  The subscription-based XM NavWeather™ service allows the navigation system to display weather information on the map screen.
- **XM NavTraffic®***3
  The subscription-based XM NavTraffic® service allows the navigation system to display traffic information on the map screen.

The following navigation-based Lexus Enform features are available without a subscription:

- Lexus Insider
  Lexus Insider is an optional service that can send audio messages, or articles, to participating owner's vehicles via the navigation system. Potential Lexus Insider subjects might include, for example, Lexus vehicle technology tips, updates on regional Lexus events, or audio excerpts from Lexus Magazine articles. Up to 20 articles can be stored at a time.
- Voice Command
  The voice command system enables you to operate the navigation system, audio/video system, air conditioning system and hands-free system by giving a command.

*1: U.S. Patent No. 7,508,298 B2

*2: Available at no extra charge with an active XM satellite radio subscription.

*3: Available via separate XM subscription(s).

■ Subscription

After you have signed the Telematics Subscription Service Agreement and are enrolled, you can begin receiving services. A variety of subscription terms is available for purchase.
Contact your Lexus dealer, call 1-800-25-LEXUS (1-800-255-3987), or select "Destination Assist" in your vehicle for further subscription details. XM NavTraffic®, XM NavWeather™ and XM TravelLink require separate XM subscription(s). XM Sports*, XM Stocks* and XM Fuel Prices are available with an XM TravelLink subscription. After a 90-day trial, you must contact XM and set up the appropriate XM subscription(s) to continue receiving these services.

*: XM Sports and XM Stocks are included with an XM Satellite Radio subscription.